


Usermanagement

Version 11.1

Date 2020.10.12



This Document describes all webservices for creating new plus altering and deleting existing users.

Table of contents

```
Table of contents
Commands
   Get all available users
       getuserlist2
       Response
   Get all details for a user
       getuser/{uuidUser}
       Response
   Get all configurable user-groups
       <u>aetarouplist</u>
       Response
   Create or Edit existing user
       addoredituser/{ison}
       Example - Add a new user
           Request
           Response
       Example - Existing User → groups and NFC-tags are adapted
   Create User
       createuser/{username}
   Delete User
       deleteuser/{uuidUser}
   Assign user to group
       assignusertogroup/{uuidUser}/{uuidGroup}
```

Usermanagement Page 2 of 13

```
Remove user from group
       removeuserfromgroup/{uuidUser}/{uuidGroup}
   Update user password
       updateuserpwdh/{uuidUser}/{value}
   Update user Visu-password
       updateuservisupwdh/{uuidUser}/{value}
   <u>Update user keycodes</u>
       updateuseraccesscode/{uuidUser}/{newAccessCode}
   Assign NFC tag to user
       addusernfc/{uuidUser}/{nfcTagId}/{name}
   Remove NFC tag from user
       removeusernfc/{uuidUser}/{nfcTagld}
Required Rights
Detailed info on attributes
   userstate
   type
   userrights
   validUntil
   validFrom
   changePassword
   name
   userid
   uuid
   <u>isAdmin</u>
   masterAdmin (deprecated)
   usergroups
       getuser/{uuidUser}
```

Version 11.1

Usermanagement Page 3 of 13

```
getgrouplist
nfcTags
keycodes
scorePWD
scoreVisuPWD
```

<u>hashing</u>

Commands

- In front of each command there is written "/jdev/sps/".
- It describes the path to the available commands.
- Commands need to be performed by a user with a right to modify other users.

Get all available users

getuserlist2

• gets a list of all configured users

Response

```
"name":"Administrator",
    "uuid":"089396d4-0207-0119-19000000000000",
    "isAdmin":true,
    "userState": 0

},

"name":"Feuerwehr",
    "uuid":"0a5fa72f-018b-0050-1900000000000",
    "isAdmin":false,
    "userState": 0

},

"name":"admin",
    "uuid":"0ee1424f-006b-57d5-ffffeee000880187",
    "isAdmin":true,
    "userState": 0
}
```

Version 11.1

Usermanagement Page 4 of 13

Get all details for a user

getuser/{uuidUser}

This webservice returns a json with the full user-configuration.

Response

```
"name": "admin",
"userid":"1234 24 12 83",
"<u>uuid</u>":"12eebb90-00a1-3073-ffff88c561c84c44",
"isAdmin":true,
"masterAdmin":true,
"changePassword":true,
"userstate":2,
"validUntil": {SECONDS SINCE 2009},
"validFrom": {SECONDS_SINCE_2009},
"userRights":2047,
"scorePWD":2,
"scoreVisuPWD":-2,
"usergroups":[
              "name": "Administratoren",
              "<u>uuid</u>":"12eebb90-00a1-3076-ffff88c561c84c44"
       },
              "name": "Alle",
              "uuid":"12eebb90-00a1-307c-ffff88c561c84c44"
],
"nfcTags":[
              "name": "NFC-Tag",
              "id":"12 34 56 78 90 98 76 54"
],
"kevcodes":[
              "code":"6C3A7D85A4B196E37C5DADFDE7E0586ED4D7137C"
]
```

Version 11.1

Usermanagement Page 5 of 13

Get all configurable user-groups

getgrouplist

Lists all available user-groups and additional information

Response

```
[
              "name": "Administratoren",
              "description": "Administratoren",
              "<u>unid</u>":"12eebb90-00a1-3076-ffff88c561c84c44",
              "<u>type</u>":1,
              "<u>userRights</u>":4294967295
              "name": "Benutzer",
              "description": "Benutzer",
              "<u>uuid</u>":"12eebb90-00a1-307a-ffff88c561c84c44",
              "type":0,
              "userRights":1
              "name": "Alle",
              "description": "Alle",
              "uuid":"12eebb90-00a1-307c-ffff88c561c84c44",
              "<u>type</u>":2,
              "userRights":0
              "name": "Niemand",
              "description": "Niemand",
              "uuid": "12eebb90-00a2-3080-ffff88c561c84c44",
              "tvpe":3,
              "userRights":0
```

Create or Edit existing user

addoredituser/{json}

- {json}:
 - User configuration with all settings to be created / changed
 - see <u>getuser-cmd</u> for details on JSON structure

Version 11.1

Usermanagement Page 6 of 13

- json-content:
 - uuid: [optional]
 - if null, a new user will be created.
 - if provided and uuid is found, an existing user is adapted.
 - if not found, it will return with code 500, user not found.
 - usergroups
 - When during editing a user and no groups-array is set, the group-assignment will remain unchanged.
 - All other json attributes are optional.
- Return-Value:
 - UUID of created or adapted user
 - o errortext if failed

Example - Add a new user

Request

```
jdev/sps/addoredituser/{"name":"A","userid":"1234","changePassword":true,"userState
":4,"validUntil":371738510,"validFrom":371736410}
```

Please note, that here no UUID is specified - that is why a new user is created.

Response

```
"name": "A",
    "uuid": "16282419-0233-2026-ffffeee000240011",
    "userid": "1234",
    "isAdmin": false,
    "changePassword": true,
    "masterAdmin": false,
    "userRights": 32,
    "scorePWD": -1,
    "scoreVisuPWD": -1,
    "userState": 4,
    "validUntil": 371738510,
    "validFrom": 371736410,
    "usergroups": [],
    "nfcTags": [],
    "keycodes": []
```

Example - Existing User → groups and NFC-tags are adapted

```
"name":"ExistingUser",
"name":"133cb125-0052-f7e9-ffff88c561c84c44",
```

Version 11.1

Usermanagement Page 7 of 13

Create User

createuser/{username}

- creates an user with a given username
- result will contain the uuid of the new user

Delete User

deleteuser/{uuidUser}

- deletes an user with a given <u>uuid</u>
- All active websockets used by this user will be closed.
- When trying to delete the last admin, the Miniserver will respond with 403

Assign user to group

assignusertogroup/{uuidUser}/{uuidGroup}

- adds an existing user to a usergroup
- more information: Get all configurable user-groups

Remove user from group

removeuserfromgroup/{uuidUser}/{uuidGroup}

• removes an user from a usergroup

Update user password

updateuserpwdh/{uuidUser}/{value}

- adapts a password for an existing user
- {value}: <u>hashed</u> password-value
- optional: append password-scoring for strength of new password
 - o {value} = {hash}|{score}

Version 11.1

Usermanagement Page 8 of 13

Update user Visu-password

updateuservisupwdh/{uuidUser}/{value}

- adapts a visu-password for an existing user
- {value}: <u>hashed</u> password-value
- optional: append password-scoring for strength of new password
 - o {value} = {hash}|{score}

Update user keycodes

updateuseraccesscode/{uuidUser}/{newAccessCode}

- sets a new keycode for a user.
- to remove a keycode, simply pass in an empty string.
- {newAccessCode} → numeric code (0-9), will be hashed once stored on the Miniserver

Assign NFC tag to user

For assigning an NFC tag to a user, the tag must be read first using an NFC Code touch (see "Structure File" documentation, section "NFC Code Touch"). Once the NFC Tag ID is known it can be paired with the user.

addusernfc/{uuidUser}/{nfcTagId}/{name}

Remove NFC tag from user

The linking of an NFC tag and the user can be removed at any time.

removeusernfc/{uuidUser}/{nfcTagld}

Version 11.1

Usermanagement Page 9 of 13

Required Rights

There are 4 levels of rights which allow different levels of editing. These levels are best described via User-Roles:

Guest

- is just a normal user
- o is not allowed to edit anything

User

- has enabled "Change own password" -checkbox
- o may edit own password or visu-password

Usermanager

- is Member of a group with group-right "Usermanagement"
- o "Change own password" is automatically enabled and may not be changed
- o may fully edit own user
- o may fully edit non-Admin-users
- o is not allowed to view or edit admin-users
- o is not allowed to add any user to an admin-group

Administrator

- o is Member of group "All Access" or a group with group-right "Loxone Config"
- o may fully edit own user
- may fully edit all other users
- o is allowed to add or remove any user to/from an admin-group

	1 Administrator	2 Usermanager	3 User	4 Guest
change own password	Х	X	Х	
change own access-code	Х	Х	Х	
edit own nfc tag	Х	Х		
change Code / Tag / Pass of an administrator	Х			
change Code / Tag / Pass of non-admin	Х	Х		
add or remove user from/to admin-groups	Х			
add or remove user from/to commen groups	Х	Х		

Version 11.1

Usermanagement Page 10 of 13

Detailed info on attributes

userstate

Indicates whether or not a user is active and may log in or get access (depending on the rights granted in config permission management).

- 0 = enabled, without time limitations
- 1 = disabled
- 2 = enabled until, disabled after that point in time
- 3 = enabled from, disabled before that point in time
- 4 = timespan, only enabled in between those points in time

type

- 0 = Normal
- 1 = Admin (deprecated)
- 2 = All
- 3 = None
- 4 = AllAccess → New "Admin Group"

userrights

- 0x00000000 = None
- 0x00000001 = Web
- 0x00000004 = Loxone config
- 0x00000008 = FTP
- 0x0000010 = Telnet
- 0x00000020 = Operatingmodes
- 0x00000040 = Autopilot
- 0x00000080 = Expert mode Light
- 0x00000100 = Usermanagement
- 0xFFFFFF = All rights (admin)

validUntil

- Only available/required if with userstate 2 and 4
- provided as seconds since 1.1.2009 00:00:00

validFrom

- Only available/required if with <u>userstate</u> 3 and 4
- provided as seconds since 1.1.2009 00:00:00

Version 11.1

Usermanagement Page 11 of 13

changePassword

Specifies whether or not a user is allowed to change its passwords from within the apps

name

When it comes to users, this is the username that is used to login via our app.

userid

May be empty, this is the id that will be returned by the NFC permission block when granting access. E.g.

uuid

Generated by the Miniserver, unique identifier.

isAdmin

- This flag is set if the user has administrative rights on the Miniserver.
- There must be at least one user who has isAdmin set, in order to still have config access.
- Any modification that would violate this rule will result in error 403 "delete of last admin not allowed"

masterAdmin (deprecated)

In config versions prior to 11.0, there used to be one main admin, which could not be removed.

usergroups

getuser/{uuidUser}

An array containing an object for each group the user is part of. Each group object contains both the name and the UUID of the group.

getgrouplist

With this request, additional infos on the group are available, such as the <u>userrights</u> and the <u>type</u>.

nfcTags

- An array with an entry for each NFC tag associated with this user.
- Each tag is represented by a name and the NFC tag id

kevcodes

- Even though this is an array, currently there is only one keycode for each user.
- The only attribute of each keycode object is the code itself.
- The code is a hashed representation of the keycode stored.

Version 11.1

Usermanagement Page 12 of 13

scorePWD

Provides/sets info on how strong a password is.

- -2 = not specified
- -1 = empty password
- 0 = low strength
- 1 = good,
- 2 = very good,
- 3 = most powerful

scoreVisuPWD

Same like <u>scorePWD</u> but for visualization passwords. (additional password that has to be entered, even tough the connection itself is already authenticated - e.g. for disarming a burglar alarm).

hashing

Passwords are never transmitted, not even encrypted - they are hashed on the client and only the hash is being transmitted to the Miniserver. Further information on hashing is to be found in the documentation "Communicating with the Miniserver" under the "Hashing" section.

Usermanagement Page 13 of 13