


# Inbetriebnahme und Montageanleitung

## Touch & Grill Air

Art. Nr.: 100341




### 01 | Stromversorgung oder integrierter Akku



### 02 | Sensoren anschließen

### 03 | Einlernmodus – 5 Sekunden Taste 7




## Touch & Grill Air in Loxone Smart Home integrieren:

### 04 | Loxone Air Gerät einlernen:

[loxone.com/help/airdevice](https://loxone.com/help/airdevice)

### 05 | Loxone Config:

Aus dem Peripheriebaum, den Baustein "Touch & Grill Air" in die Loxone Config ziehen:



### 06 | Baustein Grill konfigurieren:

[loxone.com/help/touchandgrill](https://loxone.com/help/touchandgrill)

### 07 | Funktionsbeschreibung

[loxone.com/help/touchandgrill](https://loxone.com/help/touchandgrill)


#### Published by

Loxone Electronics GmbH  
Smart Home 1  
4154 Kollerschlag  
Austria  
Tel: +43 7287 7070-0  
loxone.com

# Pairing and installation instructions

## Touch & Grill Air

Part No.: 100341



### 01 | Power supply or integrated rechargeable battery



US Adapter



UK Adapter




EU Adapter



+ Micro USB & USB

### 02 | Connect sensors

**03 | Learn-in Mode – 5 seconds key T7**




**Integrate Touch & Grill Air in your Loxone Smart Home:**

**04 | Learn-in Loxone Air device:**

[loxone.com/help/airdevice](http://loxone.com/help/airdevice)

**05 | Loxone Config:**

Pull the "Touch & Grill Air" module from the peripheral tree into the Loxone Config:



**06 | Configure Grill module:**

[loxone.com/help/touchandgrill](http://loxone.com/help/touchandgrill)

**07 | Description of function**

[loxone.com/help/touchandgrill](http://loxone.com/help/touchandgrill)

**Published by**

Loxone Electronics GmbH  
Smart Home 1  
4154 Kollerschlag  
Austria  
Tel: +43 7287 7070-0  
loxone.com