


Inbetriebnahme & Montageanleitung

Touch Nightlight Air


Art. Nr.: 100340



1 | Stromversorgung



2 | Tastenbeschreibung



3 | Einlernmodus – 5 Sekunden Taste T7



4 | Loxone Air Gerät einlernen:

loxone.com/help/airdevice


5 | Verbinden von T5, Wecker und Smartaktor:

loxone.com/help/smartaktor

loxone.com/help/touchnightlight

6 | Loxone Config:

Aus dem Peripheriebaum „Touch Nightlight Air“, die zur Verfügung stehenden Module in die Loxone Config ziehen.



7 | Baustein Wecker konfigurieren:

loxone.com/help/alarmclock

8 | Funktionsbeschreibung

loxone.com/help/touchnightlight

Published by

Loxone Electronics GmbH
Smart Home 1
4154 Kollerschlag
Austria
Tel: +43 7287 7070-0
loxone.com



Pairing and installation instructions

Touch Nightlight Air

Part No.: 100340



1 | Power supply



US Adapter



UK Adapter




EU Adapter



+ Micro USB & USB

2 | Key description



3 | Learn-in Mode – 5 seconds key T7



4 | Learn-in Loxone Air device:

loxone.com/help/airdevice


5 | Connecting T5, alarm clock and smart actuator:

loxone.com/help/smartaktor

loxone.com/help/touchnightlight

6 | Loxone Config:

Pull the "Touch Nightlight Air" module from the peripheral tree into the Loxone Config:



7 | Configure alarm clock module

loxone.com/help/alarmclock

8 | Description of function

loxone.com/help/touchnightlight

Published by

Loxone Electronics GmbH
Smart Home 1
4154 Kollerschlag
Austria
Tel: +43 7287 7070-0
loxone.com