

## Technical Specifications

<b>Power Supply</b>	9...28VDC SELV
<b>Maximum Loxone Air Devices</b>	128
<b>Antenna</b>	External stub-antenna provided
<b>Power Consumption</b>	max. 150mW
<b>Total Power Loss</b>	max. 150mW
<b>Safety Protection</b>	IP20
<b>Ambient Temperature</b>	-40...70°C / -40...158°F
<b>Humidity</b>	95% r. H. (non condensing)
<b>Radio Frequency</b>	868MHz (SRD Band Europe), 915MHz (ISM Band Region 2) max. Power 3.16mW
<b>Dimensions</b>	35.5x88x57mm / 1.4x3.46x2.24" (LxWxH)
<b>Maintenance &amp; Cleaning</b>	The device is free of maintenance and may only be cleaned with a dry cloth.

# LOXONE

## Need Help?

2 H H = ü ' ð H ; ° m • c c H f w

Loxone Electronics GmbH

• ; Ö f w C H ; ü /  
2 / 3 2 Y H 2 2 ü f m ð 2 Ö  
• m w f Ö

loxone.com



# LOXONE



f Ö m ü  
) w ü = m H =

Ö f w f H - / . . / 2

## About the product

Connect up to 128 Loxone Air devices using the Air Base Extension.

## Features

- 128 Air devices

## Installation

The installation of the device has to be mounted on a DIN rail in an electrical distribution housing and may only be performed by qualified personnel.

Protection against electrical contact and fire protection must be provided in the final installation by the use of a standard compliant/approved housing.

If the unit is used in a non conform manner as specified by the manufacturer the product included safeguards will be impaired.

This folder is a part of the product!



For additional information, declaration of conformity, visit [www.loxone.com/help/air-base-extension](http://www.loxone.com/help/air-base-extension)

## Connection

<b>Wire Diameter</b>	0.25...0.8mm <sup>2</sup> / AWG23...AWG18
<b>Exposed Wire Length</b>	5mm / 0.2"
<b>Push-In-Technology</b>	To make connection, insert wire. To remove the wire, twist and pull the wire at the same time.

## Information

Contains FCC ID: COR-ZWIR4512AC1

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation

