

About the product

Loxone Valve Actuator Air offers smart heating and cooling control on a room-by-room basis.

Features

- Valve control
- Interchangeable valve adapters (VA80 included)

Installation & electrical connection

Mounting of the equipment must be performed by a qualified technician. During mounting and in case of error a separator (at least 4A) must be present to turn off the supply. The separator must be easily accessible and recognizable.

This folder is a part of the product!



For additional information, declaration of conformity, visit www.loxone.com/help/valve-actuator-air

Connection

Cross-section	0.26 ... 0.34mm / AWG23 ... 22
Stripping length	1.1 ... 1.6mm / 0.043" ... 0.063"
Temperature resistance	-40 ... 105°C / -40 ... 221°F
	The wires to be connected into a termination terminal. The connection terminals are not so sensitive in an installation.

Information

Contains FCC ID: COR-ZWIR4512AC1

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation

