

## Technical Specifications

<b>Power Supply</b>	110/230VAC
<b>Standby Power</b>	< 0.5W
<b>Output</b>	1 Relay Output (switches input power)
<b>Max. Load</b>	Plug Type E - 13A Plug Type F - 13A Plug Type J - 10A Plug Type G - 13A
<b>Power and Energy Measurement</b>	Yes
<b>Temperature Detection Range</b>	-40...125°C / -40...257°F
<b>Radio Frequency</b>	868MHz (SRD Band Europe) 915MHz (ISM Band Region 2)
<b>Ambient Temperature</b>	-20...35°C / -4...95°F
<b>Humidity</b>	95% r.H. (non condensing)
<b>Safety Protection</b>	IP20
<b>Maintenance &amp; Cleaning</b>	This device is free of maintenance and may only be cleaned with a dry cloth.

# NEED HELP?

For further information and documentation please visit:  
[www.loxone.com/help/smart-socket-air](http://www.loxone.com/help/smart-socket-air)



**LOXONE** Smart Home

GET IN TOUCH!

[office@loxone.com](mailto:office@loxone.com)

[www.loxone.com/contact](http://www.loxone.com/contact)

[www.loxone.com](http://www.loxone.com)



# SMART SOCKET AIR

Part No.: 100120 Plug Type E

Part No.: 100115 Plug Type F

Part No.: 100121 Plug Type G

Part No.: 100119 Plug Type J



## About the Product

The Smart Socket Air gives you simple and convenient wireless control of devices and appliances.

With an in-built temperature sensor and power monitor, you can easily keep track of how much energy your appliances are using, and switch them off remotely via the Loxone app.

## Features

- Freely programmable relay output
- Power and energy measurement
- Temperature sensor

## Installation

The installation of the device has to be carried out by a qualified person. The device has to be fitted in accordance with building regulations for electrical and fire safety. If the device is not installed according to manufacturers guidelines the protection of the device may be affected. Prior to the installation it's important to read our online documentation.

When the Smart Socket Air is first plugged in, learning mode will be activated for 10 minutes or until the device has been successfully paired with a Miniserver using Loxone Config.



For our safety information and declaration of conformity, visit [www.loxone.com/help/smart-socket-air](http://www.loxone.com/help/smart-socket-air)

## Information

Contains FCC ID: COR-ZWIR4512AC1

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. *This device may not cause harmful interference*
2. *This device must accept any interference received, including interference that may cause undesired operation*

